

**NEW**

# ASSET GUARD

## LTE-M / NB-IoT

Ultra-rugged and compact Indoor/Outdoor asset tracker. Features cloud-based location solving for 10+ years of battery life.



### Indoor/Outdoor

GNSS, Wi-Fi AP MAC Address Scanning, and Cell Tower location fallback for seamless indoor/outdoor asset management



### 'Deploy Once' Battery Life

Over 10+ years battery life on only 3 x AAA user-replaceable batteries



### Cloud-Based Location

Position calculations are handled in the cloud (versus on-device) for substantial power savings



### Adaptive Tracking

Periodic or optional movement-based tracking - tracks assets throughout the day and/or when movement occurs, entering sleep mode when inactive to conserve power and data usage



### Battery Life Alerts

"Battery Low" and "Battery Critical" alerts



### Ultra-Rugged

Ultra-rugged and weatherproof IP68, IK06 Housing

# Connectivity

|   |   |
|---|---|
| <b>LTE-M / NB-IoT</b><br>(supports roaming between networks - roaming SIM required) | Nordic nRF9160 Modem operates on all major global LTE-M and NB-IoT bands.<br>Supported LTE bands:<br>LTE-M (Cat-M1): B1, B2, B3, B4, B5, B8, B12, B13, B14, B17, B18, B19, B20, B25, B26, B28, B66<br>NB-IoT (Cat-NB1/NB2): B1, B2, B3, B4, B5, B8, B12, B13, B17, B19, B20, B25, B26, B28, B66 |
| SIM Size & Access   | Internal Nano 4FF SIM ( <b>Included</b> )   |

# Batteries

|                            |  |
|----------------------------|--|
| User-Replaceable Batteries | 3 x AAA. <i>Batteries not included.</i>  |
| Supported Battery Types    | Lithium (LiFeS2) – Lithium recommended for best performance<br>*Please dispose of Lithium batteries in a safe and responsible manner |
| **Battery Life Estimates   | Once Daily location updates – 10+ years<br>Movement-Based location updates – 3.5 years<br>Hourly location updates – 2 years          |

# Location

|                      |  |
|----------------------|--|
| Chipset              | Semtech LR1110   |
| Constellation        | Concurrent GPS and BeiDou  |
| Cloud-Based Solver   | Asset location is calculated in the cloud with GNSS/Wifi data  |
| Tracking Sensitivity | -134 dBm autonomous / -141 dBm aided   |
| GNSS Assistance      | GNSS almanac data for greater sensitivity and position accuracy  |
| Low Noise Amplifier  | GPS signals are filtered and boosted by a SAW filter and low-noise amplifier (LNA) allowing operation where other units fail |
| Cell Tower Location  | Cell tower fallback for positioning when there is no GNSS or Wi-Fi signal  |
| Wi-Fi Positioning    | Indoor asset location using Wi-Fi access point scanning (device does not connect to Wi-Fi)                                   |

# Power

|               |  |
|---------------|--|
| Input Voltage | 3-5.5V DC  |
| Sleep Current | <10uA*<br>*Average current in lowest power configuration |

# Mechanics / Design

|            |  |
|------------|--|
| Dimensions | Standard - 84 x 63 x 24 mm (3.31 x 2.48 x 0.94")<br>Livestock Collar - 109 x 60 x 30 (4.29 x 2.36 x 1.18")<br>Snap Housing (Smallest Size, not IP67 rated) - 75 x 45 x 25 mm (2.95 x 1.77 x 0.98") |
| Weight     | Standard - 82 g (2.9 oz)   |
| Housing    | Rigid plastic  |

## Mechanics / Design *(continued)*

|                       |   |
|-----------------------|---|
| IP/IK Rating          | Ultra-rugged and waterproof IP68 and IK06-rated housing ensures the AssetGuard can withstand impact, fine dust, and brief submersion  |
| Installation          | Compact and concealable. Multiple installation options for covertly and easily securing the device to assets with screws, bolts, cable ties, rivets, and more. Collar housing available for securing device to livestock. |
| Operating Temperature | -30°C to +60°C  |
| Cellular Antenna      | Internal  |
| GPS Antenna           | Internal  |
| Wi-Fi Antenna         | Internal  |
| 3-Axis Accelerometer  | 3-Axis Accelerometer to detect movement, high G-force events, and more  |
| Diagnostic LED        | Diagnostic LED indicates operation status   |
| Flash Memory          | Store weeks of records if device is out of cellular coverage. Storage capacity for over 5 days of continuous 30-second logging.   |
| Speed and Heading     | Scanning technology used on the AssetGuard does not return speed and heading  |
| On-Board Temperature  | The device reports internal temperature which provides an indication of ambient temperature but may not always be precise   |

## Smarts

|                                     |  |
|-------------------------------------|--|
| Auto-APN                            | Auto-APN allows the device to analyze the SIM card and select the correct APN details from a list that is pre-loaded in the device's firmware  |
| Battery Life Monitoring             | “Battery Low” and “Battery Critical” alert levels  |
| Geofence Alerts                     | The server can use device location to create geofences and alerts if an asset enters or leaves designated locations  |
| Impact Detection                    | Configure impact-detection alerts when G-forces are exceeded by a user-defined threshold   |
| Intelligent Power Management        | Early registration abort and location scan throttling options  |
| Periodic or Movement-Based Tracking | Configure parameters to send updates based on set time intervals or when movement occurs. Adaptive tracking technology detects when the device is on the move and increases the update rate, providing detail when you need it while conserving battery when stationary. |
| Preventative Maintenance            | Set reminders based on distance traveled and run hours to reduce maintenance and repair costs  |
| Run Hour Monitoring                 | Set reminders based on movement to understand and optimize asset utilization   |
| Sleep Mode                          | Stationary devices enter sleep mode until movement occurs to conserve battery life and optimize data usage   |
| Theft Recovery                      | Switch to Recovery Mode in the case of theft or loss to activate real-time tracking for asset retrieval  |
| Tip Detection & Rotation Counting   | Axis angle reporting, tip detection and rotation counting  |

## Device Management

|                            |   |
|----------------------------|---|
| Flexible Configuration     | Configure device parameters such as position update rate, movement and accelerometer settings, and more to fit any tracking application |
| Device Management Platform | Manage, monitor, configure, debug, update, and restart devices remotely from our cloud-based device management system                   |

# Security

---

|               |   |
|---------------|---|
| Data Security | Military-level AES-256 Encryption from device to Device Management Platform to protect the integrity and confidentiality of telematics data. Data forwarded to third-party systems is sent via HTTPS for end-to-end security. |
|---------------|---|

---

# Warranty

---

|                         |                                  |
|-------------------------|----------------------------------|
| Manufacturer's Warranty | Two-year manufacturer's warranty |
|-------------------------|----------------------------------|

---

# Certifications

Please enquire directly for a full list of compliance specifications and documentation for your region

**LTE-M / NB-IoT** - FCC, ISED, UKCA, CE, ICASA, AMCA RCM, EMC, RoHS, PTCRB, AT&T, US Cellular

\*\*Battery life estimates are influenced by several factors including temperature, installation and orientation of the device, the frequency of location updates, network coverage, sensor integrations, peripherals, accelerometer settings, and more. Estimated battery life calculators are available.